HIGOLD

Shearer Three /four Sides Pull Out Basket

Installation manual

Shearer Series

HBB-F

01

Accessories List

The minimum depth of the basket is 400mm, and the minimum installation height is 125mm. The width should be selected according to the cabinet size. Please pay attention to the cabinet size when installing.

Three Sides Basket*1 or Four Sides Basket*1

Slide rail 1*2, Install template *1

Slide rail dust cover *1, self-tapping screws pack *1 (M 3.5*16 drill self-tapping screws for the three sides basket, ST 4.1*26 self-tapping screws for the four sides basket)

The three sides basket has the following additional accessories compared with the four sides basket

Door panel decoration cover *2, Fully threaded screw *2

Door panel fastener*2, Flat M4*10mm screws and four M4*10mm screws are pre-installed on the door panel fastener)

02

Installation of the slide rail

Use the bottom edge of the cabinet and the door edge as the reference, and use the installation template to pre-drill holes (left/right).

Install the slide rails (left/right). Align the slide rail fixing hole with the pre-drilled holes and lock them with ST4.0*16mm self-tapping screws (note to use the full dust cover).

The installation method for the slide rails of the three sides basket and four sides basket is the same. The installation of the slide rails is completed.

03

Installation of the Three sides basket

Insert the rail tail hook into the rear groove of the three sides basket (left/right).

Then use the clips at the bottom of the basket to clamp the front ends of the guide rails (left /right).



The main body of the three sides basket is installed.

04

Installation of the three sides basket panels

Pretreatment of door panel fixings:
Remove the M4*10mm screws at the bottom, and unscrew the upper M4*10mm screws and M4*12mm screws to a certain length.

Specification	150	200	250	300	350	400
A	96	96	96	96	96	96
B	96	96	96	96	96	96
C	96	96	96	96	96	96

Standard length door panel fixings can be pre-drilled according to the above dimensions. Other non-standard length door panels need to be pre-drilled after precise measurement of the matching distance between two door panel fasteners.

Use the standard length cabinet door panel, take the bottom edge of the door panel as the reference, and use the installation template to pre-drill holes (left/right).

Install the door panel fasteners (left/right). Align the door panel fixing holes with the pre-drilled holes and lock them with four ST4.2*16mm self-tapping screws.

Hang the door panel into the hole of the three sides basket corner fittings.

Lock the two pre-removed M4*10mm screws into the corner fittings (left/right).

Lock the fully threaded screws into the corner fittings of the three sides basket (for adjusting the door panel).

Adjust the upper and lower M4*10mm screws and fully threaded screws to ensure the door panel fits tightly and flush with the cabinet, then tighten the four M4*10mm screws to secure the door panel.

Install the door panel decorative cover and push it into the slot from top to bottom.

The low top three sides basket is installed.

05

Installation of the four sides basket

Insert the rail tail hook into the rear groove of the four sides basket (left/right).

Then, use the clips at the bottom of the basket to clamp the front ends of the guide rails (left /right).

The four sides basket installation is completed.

Note: Pay attention to the installation sequ of multi-layer installation, so as not to have basket body pull-out interference after assembly. When installing the upper layer, press the top edge of the lower door panel as the reference.

HIGOLD